

RECORDING TELEPHONE CALLS

What you'll need:

1. Cell phone with 1/8" headphone plug.
2. TASCAM DR-40 or similar recorder with two 1/4" inputs.
3. RCA stereo audio cable
4. RCA to male 1/8" adapter
5. Two RCA to 1/4" male adapters
6. 1 set of cell phone headphones (iPhone earbuds work great) with an in-line hands free mic.

Directions:

1. Plug the RCA to 1/8" adapter into the headphone jack on your phone.
2. Plug the RCA stereo cable into the RCA to 1/8" adapter
3. Plug the RCA stereo cable into the RCA to 1/4" adapters
4. Plug the 1/4" adapters into the external mic inputs on TASCAM DR-40
5. Plug the headphones or earbuds into the headphone jack on your TASCAM DR-40
6. Set the Rec Mode to stereo ext mic 1/2
7. Start recording on the DR-40
8. Make your call. Set the input level to the proper level and record your interview.

